

V108i Temperature/Process Indicator and Alarm Unit


Installing and Operating Instructions

Thank you for choosing the 1/8 DIN indicator and alarm unit. It will provide accurate measurement and display of temperature and other process variables with up to two alarm outputs for operation alert and process protection.

Identification Labels


The indicator is identified by a label fixed to the top of the case which gives the serial number and ordering code. The ordering code defines the configuration of your particular indicator. Details of the code are given on page 7.

DIMENSIONS AND INSTALLATION




Latching ears (top & bottom)

Panel retaining clips (both sides)



ELECTRICAL CONNECTIONS




To install the indicator

Please read the safety information on pages 7 & 8 before proceeding.

1. Prepare the panel cut-out to the size shown.
2. Insert the indicator through the cut-out.
3. Spring the panel retaining clips into place. Secure the indicator in position by holding it level and pushing both retaining clips forward.
4. Peel off the plastic film protecting the front of the indicator.

Unplugging the indicator

The indicator can be unplugged from its sleeve by easing the latching ears outwards and pulling it forward out of the sleeve. When plugging the indicator back into its sleeve, ensure that the latching ears click into place to maintain the IP54 sealing.



Relay Ratings

2A, 264Vac resistive


Wire Sizes

The screw terminals accept wire sizes from 0.5 to 1.5 mm (16 to 22 AWG). Hinged covers prevent hands or metal making accidental contact with live wires. The rear terminals screws should be tightened to 0.4Nm (3.5lb in).

CE This indicator meets the European directives on safety and EMC.

OPERATION

Switch on the indicator. After a 3 second self-test sequence, you will see the display shown below. It is called the HOME display.



ALARM INDICATION

The three internal alarms are configurable as high, low or rate of change alarms which alert an operator when a pre-set level (setpoint) has been exceeded. They are flashed as messages in the main display with the following meaning:

| Display | Meaning |
|---------|---|
| 1--- | Alarm_1 is true |
| 2--- | Alarm_2 is true |
| 3--- | Alarm_3 is true |
| 5br | Sensor Break alarm (open circuit input) |

In place of dashes the last three letters indicate the alarm type: **FSL** = Full Scale Low alarm, **FSH** = Full Scale High alarm, **rAL** = Rate of change alarm.
If other messages are flashed, see **DIAGNOSTIC ALARMS** on page 4.


Any combination of the four alarms shown in the table above can operate relay outputs 1 & 2. These would normally provide plant safety interlocks or external audio/visual indication. Alarms are assigned to the relay outputs in accordance with the ordering code.

A relay will operate when any alarm attached to it becomes true. The corresponding beacon, OP1 or OP2 will flash when a new alarm occurs and go steady when the ACK/RESET button is pressed. The relay will remain in the alarm state while the alarm condition persists.

Pressing the ACK/RESET button will acknowledge new alarms and reset any latched alarms that are no longer true.

TO VIEW THE DISPLAY UNITS

In addition to the label set shown on page 1, the temperature units for thermocouple and RTD inputs, are flashed in the main display, as follows: Press and quickly release the **[D]** or **[C]** button. The display units will be flashed for 0.5sec




If, at any time you get lost, pressing **[D]** and **[C]** together will always return you to the HOME display.

If, at any time, no key is pressed within 45 seconds, the display will always return to the HOME display.

HOME DISPLAY OPTIONS

When shipped from the factory the HOME display will, by default, show the measured temperature (or PV). You can select alternative HOME displays as follows:




To prevent an Operator changing this option, see

TO HIDE, REVEAL AND PROMOTE PARAMETERS Page 4.

TO CHANGE THE ALARM SETPOINTS (TRIP LEVELS)

The **[D]** button steps through parameter list headings as shown on page 3. The first list is the alarm setpoints list **AL**.

Quickly press **[D]** twice to choose the **AL** list.




Note: The other parameters listed on page 3 are accessed and adjusted in exactly the same way as this example.

PARAMETER LISTS

Use these lists to change:

- The alarm setpoints (as shown on the previous page)
- The alarm setpoint limits
- The input filter time constant
- User calibration.

The diagram shows the full list of possible parameters. Some may not appear, however, because they are dependant upon the configuration of the indicator.



Select or change parameters

1. Press **[D]** to step across the list headings.
2. Press **[G]** to step down the parameters within a particular list. You will eventually return to the list heading.
3. Press **[V]** to view the value of a selected parameter. Keep pressing to decrease the value.
4. Press **[A]** to view the value of a selected parameter. Keep pressing to increase the value.

PARAMETER TABLES

| HOME | Home List | Selectable options | Default setting | Customer setting |
|-------|------------------------------|--|-----------------|------------------|
| d, SP | HOME <u>d</u> isplay options | See HOME DISPLAY OPTIONS page 2 | PU | |

| AL | Alarm setpoints | Adjustable Range | Default setting | Customer setting |
|------|---|---|----------------------|------------------|
| 1--- | Alarm <u>1</u> setpoint | Between low and high setpoint limits. Note: If the alarm is disabled, the parameter will not appear. | 0 | |
| 2--- | Alarm <u>2</u> setpoint | | 0 | |
| 3--- | Alarm <u>3</u> setpoint | | 0 | |
| HY | Alarm <u>H</u> ysteresis Prevents relay 'chatter' by setting a difference between relay turn ON and relay turn OFF value | 1 to 9999 display units | 1 | |
| 1dEL | Alarm <u>1</u> delay | Used to ignore transient alarms. Alarms must be true for the set time before they become active | OFF to 999.9 seconds | 0 |
| 2dEL | Alarm <u>2</u> delay | | OFF to 999.9 seconds | 0 |
| 3dEL | Alarm <u>3</u> delay | | OFF to 999.9 seconds | 0 |

*In place of dashes, the last three letters indicate the alarm type: **FSL** = Low alarm. **FSH** = High alarm. **rAL** = Rate of change alarm

| SP | Setpoint limits | Adjustable Range | Default setting | Customer setting |
|------|---|---|-----------------------------------|---------------------------------|
| SP L | Alarm <u>s</u> etpoint <u>l</u> ow limit | Prevents alarms from being set out of range | Between Process Value min and max | As order code else PV min & max |
| SP H | Alarm <u>s</u> etpoint <u>h</u> igh limit | | | |

| ,P | Input List | Adjustable Range | Default setting | Customer setting |
|------|---|--|------------------------------|------------------|
| F,LT | Input <u>f</u> ilter time constant Reduces display flicker due to process noise. | OFF to 999.9 seconds | 1.5 | |
| CJCO | <u>C</u> old junction <u>c</u> ompensation temperature (T/C inputs only) measured at the rear terminals. | | Read-only | Read-only |
| mU | <u>m</u> V input measured at the rear terminals | | Read-only | Read-only |
| OFS | PV <u>o</u> ffset Customer set fixed calibration offset which applies over the whole display range | - 1999 to 9999 display units | 0 | |
| CALP | <u>C</u> alibration <u>p</u> assword (See USER CALIBRATION) | 0 to 9999 | 3 | |
| CAL | <u>C</u> alibration type. | FACT Restores <u>F</u> actory calibration USER <u>U</u> ser calibration applies | FACT | |
| PntL | <u>L</u> ow calibration <u>p</u> oint | These parameters appear only if USER calibration selected | - 1999 to 9999 display units | 0 |
| OFSL | <u>L</u> ow point <u>o</u> ffset | | - 1999 to 9999 display units | 0 |
| PntH | <u>H</u> igh calibration <u>p</u> oint | | - 1999 to 9999 display units | 100 |
| OFSH | <u>H</u> igh point <u>o</u> ffset | | - 1999 to 9999 display units | 0 |


| ACCS | Access list | Used for re-configuring the indicator. See the next page for details |
|------|-------------|--|
|------|-------------|--|

TO HIDE, REVEAL AND PROMOTE PARAMETERS


The *Pro* (Promote) option

Up to twelve commonly used parameters can be ‘promoted’ into the HOME list. This will give the operator quick access to them by simply pressing the button. This feature, used in combination with ‘hide’ and ‘read only’, allows you to organize the way in which you want your indicator formatted.


Select EDIT level to hide, reveal or promote parameters as below:



Edit Level Example:




Promote Level Example:



The parameter *iFSL* will now appear in the HOME list. Repeat the procedure for any other parameters you wish to promote. To de-promote a parameter go to *Edi t* level, select the parameter from the relevant list and change the choice from *Pro* back to *ALtE*, *rEAd* or *Hi dE*.

Returning to Operator level

Repeat the above procedure for all the parameters you wish to hide, promote, or make read-only then return to operator level:




USER CALIBRATION

Your indicator has been calibrated for life against known reference sources in the factory. User calibration allows you to apply offsets to compensate for sensor and other system errors. You can apply a simple fixed offset over the whole display range using the parameter *DFS* in the *P* list, or alternatively, you may apply a 2-point calibration as follows:

- Press until you reach the *P* list
- Press until you reach the *CALP* parameter
- Press or to enter the password. The factory default password is 3. *PASS* will be displayed when correct.
- Press to reach the *CAL* parameter
- Press or to select *USER* (*FACT* will restore the factory calibration)
- Press to select *PntL*
- Press or to adjust the value at which you wish to apply the low calibration point offset. (e.g. zero)
- Press to select *DFS*
- Press or to set the low calibration point offset.
- Repeat the above to select and adjust *PntH* and *DFS*

The graph below shows the effect of a low and high point offset.




DIAGNOSTIC ALARMS

These warn that a fault exists in either the indicator or the connected devices.

| Alarm | What it means | What to do about it |
|-------|---|---|
| EE.Er | <i>Electrically Erasable Memory Error</i> : The value of an operator or configuration parameter has been corrupted. | This fault will automatically take you into configuration level. Check all of the configuration parameters before returning to operator level. Once in operator level, check all of the operator parameters before resuming normal operation. If the fault persists or occurs frequently, contact your agent. |
| S.br | <i>Sensor Break</i> : Input sensor is open circuit. | Check that the sensor is correctly connected. |
| LLLL | <i>Out of range low reading</i> | Check the value of the input |
| HHHH | <i>Out of range high reading</i> | Check the value of the input |
| Err1 | <i>Error 1</i> : ROM self-test fail | Return the indicator for repair |
| Err2 | <i>Error 2</i> : RAM self-test fail | Return the indicator for repair |
| Err3 | <i>Error 3</i> : Watchdog fail | Return the indicator for repair |
| Err4 | <i>Error 4: Keyboard failure</i> Stuck button, or a button was pressed during power up. | Switch the power off and then on without touching any of the indicator buttons. |

CONFIGURING THE INDICATOR


To select configuration level



Select configuration level to change:

- The display units
- The input sensor type
- The scaling of linear inputs
- The alarm configuration
- The relay output configuration
- The passwords.

To Exit Configuration level



| Inst | Instrument configuration list | Options | Meaning | Default setting | Customer setting |
|-------|--|------------------------|---|--|------------------|
| unit | Display <u>units</u> | °C °F °K none | Celsius Fahrenheit Kelvin None (for linear inputs) | Defined by the ordering code, otherwise °C | |
| decP | Decimal <u>places</u> in display | none one two | None One Two | Defined by the ordering code, otherwise none | |
| Ac bu | Front panel <u>Ack/Reset</u> button enable | YES no | YES = Button enabled no = Button disabled | YES | |

| IP | Sensor Input configuration list | Options | Meaning | Default setting | Customer setting |
|------|--|--|---|--|------------------|
| inpT | <u>Input type</u> NOTE: After selecting an input type, do not forget to adjust the setpoint limits in Full Access level. | Jtc Ktc Ltc rtc btc ntc Itc Stc PL 2 rtd Ctc mV | ↓ thermocouple K thermocouple L thermocouple R thermocouple B thermocouple N thermocouple I thermocouple S thermocouple Platinell II 100Ω Platinum resistance thermometer Custom input C thermocouple = default* Linear milli volt | Defined by the ordering code otherwise Ktc * If a different custom input is supplied, Ltc will be replaced by the table reference number listed on page 7, Ordering Code | |
| CJC | <u>Cold junction compensation</u> (CJC does not appear for mV or rtd inputs. For mV see 'Linear input scaling' on page 6) | Auto 0°C 45°C 50°C | Automatic 0°C external reference 45°C external reference 50°C external reference | Auto | |
| imp | Sensor break input <u>impedance</u> threshold | OFF Auto Hi Hi Hi | No sensor break (linear inputs only) 1.5KΩ 5KΩ 15KΩ If the sensor input exceeds this value, the sensor break alarm will be activated. | Auto | |

| Linear input scaling (-9.99 to +80.00mV). These parameters appear after nPL whenever a linear mV input is configured. This allows the low and high displayed values to be set up against the corresponding mV inputs. | | | | | |
|---|----------------------|--|--|-----------------|------------------|
| | | | | Default setting | Customer setting |
| $InPL$ | mV input low | | | 0 | |
| $InPH$ | mV input high | | | 50 | |
| $UALL$ | Displayed value low | | | 0 | |
| $UALH$ | Displayed value high | | | 50 | |

Alarm Configuration

Alarms are used to alert an operator when a pre-set level or condition has been exceeded. They are normally used to switch a relay output - to provide interlocking of the machine or plant or external audio or visual indication of the condition.

The AL list configures the three internal 'soft' alarms and causes the appropriate alarm message to be flashed in the HOME display.

Soft Alarms are a visual warning message within the indicator. To attach a soft alarm to activate a relay see '**Relay outputs 1 and 2 Configuration**'.

| AL | Alarm type conf | Options | Meaning | Default setting | Customer setting | | |
|--------|-----------------|---------------------------------|---|--|------------------|---|---|
| $AL 1$ | Alarm 1 type | OFF FSL FSH rAL rAS | The alarm is disabled Full Scale Low alarm The PV exceeds a set low level Full Scale High alarm The PV exceeds a set high level Rate of change, -1999 to 1999 display units per min. 0 = OFF Rate of change, -1999 to 1999 display units per sec. 0 = OFF | $AL 1$, $AL 2$, and $AL 3$ As order code, otherwise OFF | Alarm number | | |
| | | | | | 1 | 2 | 3 |
| $Ltch$ | Alarm latching | no YES man | Non-latching Latched with automatic resetting (Note 1) Latched with manual resetting (Note 2) | As order code, otherwise no | | | |
| $blac$ | Alarm blocking | no YES | No blocking Blocked until first good. (Note 3) | no | | | |

The above sequence is repeated for: $AL 2$ (alarm 2) and $AL 3$ (alarm 3)

Notes:

- Automatic resetting means that, once the alarm has been acknowledged, it will automatically clear when it is no longer true.
- Manual resetting means that the alarm must first clear before it can be reset.
- In blocking mode, after power on, the process value must first enter a good state before the alarm becomes active. This is particularly useful for low alarms which can be 'blocked' while the process is warming up.

Relay outputs 1 and 2 Configuration

The RA and $3A$ lists allow the three internal 'soft' alarms to be attached to relay outputs 1 and 2 respectively.

Note: RA is the terminal number for output 1 and $3A$ is the terminal number for output 3.

| RA | Relay output 1 configuration | Options | Meaning | Default setting | | Customer setting | |
|--------|------------------------------|-------------|---|-----------------|------|------------------|------|
| $3A$ | Relay output 2 configuration | | | RA | $3A$ | RA | $3A$ |
| id | Identity of output | rELY | Relay | rELY | rELY | Read only | |
| $Func$ | Function of output | nonE diG | None Output disabled Digital alarm output | diG | diG | | |
| $SENS$ | Sense of the output. | nor Inu | Normal (relay energized in alarm) Inverted (relay de-energized in alm) | Inu | Inu | | |

To Attach Alarms to the Relay Outputs. Any of the following alarms can be combined to operate the selected relay output. Press to select a particular alarm. Press or to select YES if you want it to operate the relay. Select no to disconnect a given alarm.

| | | Attaching alarms to a relay | | Output 1 | Output 2 | Output 1 | Output 2 |
|--------|--------------------|-----------------------------|--|---|----------|----------|----------|
| $1---$ | Alarm 1 | YES / no | | As order code otherwise no, 5br defaults to YES on both outputs | | | |
| $2---$ | Alarm 2 | YES / no | | | | | |
| $3---$ | Alarm 3 | YES / no | | | | | |
| $5br$ | Sensor break alarm | YES / no | | | | | |
| nw | New alarm | YES / no | | | | | |

* The last three letters will correspond to the alarm type set in the AL list. If the alarm is disabled, $AL 1$ or $AL 2$ or $AL 3$ will be shown.

Passwords

| PASS | Passwords configuration | Range | | Default setting | Customer setting |
|--------|------------------------------|--------|--|-----------------|------------------|
| $RECP$ | Full and Edit level password | 0-9999 | | 1 | |
| $CONF$ | Configuration level password | 0-9999 | | 2 | |
| $CALP$ | User calibration password | 0-9999 | | 3 | |

ORDERING CODE

The indicator is supplied configured according to the ordering code shown below. Here is an example model number **V108-AL/GN/VH**.

| Model number | Function | Display color | Supply voltage |
|--------------|---------------|------------------|----------------|
| V108i | AL Alarm unit | GN Green display | VH 85-264Vac |
| | | RD Red display | |

If preferred, the factory can preconfigure the indicator using the optional configuration code as a second item ordered. Here is an example configuration code, **C620-FH/FL/ENG/JJ-210/1200/C/XX**

| Configuration Model Number | Relay Output 1 | Relay Output 2 | Manual | Sensor input | Range min | Range max | Units | Input Adaptor |
|----------------------------|----------------|----------------|------------|--------------|-----------|-----------|-------|---------------|
| C620 | | | ENG | | Note 1 | Note 1 | | |

| Relay Output 1 | |
|--------------------------|----------------------------|
| XX | Not fitted |
| RF | Fitted unconfigured |
| Un latched alarms | |
| FH | High alarm 1 |
| FL | Low alarm 1 |
| AL | High alarm 1 & low alarm 3 |
| RA | Rate-of -change alarm 1 |
| Latched alarms | |
| HA | High alarm 1 |
| LA | Low alarm 1 |
| RT | Rate-of -change alarm 1 |
| AA | High alarm 1 & low alarm 3 |
| NW | New alarm status |

| Relay Output 2 | |
|--------------------------|-------------------------|
| XX | Not fitted |
| RF | Fitted unconfigured |
| Un latched alarms | |
| FH | High alarm 2 |
| FL | Low alarm 2 |
| RA | Rate-of -change alarm 2 |
| Latched alarms | |
| HA | High alarm 2 |
| LA | Low alarm 2 |
| RT | Rate-of -change alarm 2 |
| NW | New alarm status |

| Sensor input | | Range min & max limits | |
|---------------------------------|---|--------------------------|---------------|
| Thermocouples | | | |
| | | °C | °F |
| J | Type J | -210 to 1200 | -340 to 2192 |
| K | Type K | -200 to 1372 | -325 to 2500 |
| T | Type T | -200 to 400 | -325 to 750 |
| L | Type L | -200 to 900 | -325 to 1650 |
| N | Type N | -200 to 1300 | -325 to 2370 |
| R | Type R | -50 to 1768 | -58 to 3200 |
| S | Type S | -50 to 1768 | -58 to 3200 |
| B | Type B | 0 to 1820 | 32 to 3308 |
| P | Platinell II | 0 to 1369 | 32 to 2496 |
| Resistance thermometer | | | |
| Z | Pt100 | -200 to 850 | -325 to 1562 |
| Custom downloaded inputs | | | |
| | | "Table Reference Number" | |
| C | Type C -W5%Re/W26%Re (default downloaded input) | "LC" 0 to 2319 | 32 to 4200 |
| D | Type D W3%Re/W25%Re | "T035" 0 to 2399 | 32 to 4350 |
| E | E thermocouple | "T012" -200 to 999 | -325 to 1830 |
| 1 | Ni/Ni18%Mo | "T033" 0 to 1399 | 32 to 2550 |
| 2 | Pt20%Rh/Pt40%Rh | "T025" 0 to 1870 | 32 to 3398 |
| 3 | Engelhard W/W26%Re | "T09" 0 to 2000 | 32 to 3632 |
| 4 | Hoskins W/W26%Re | "T029" 0 to 2010 | 32 to 3650 |
| 5 | Engelhard W5%Re/W26%Re | "T011" 10 to 2300 | 50 to 4172 |
| 6 | Bucose W5%Re/W26%Re | "T038" 0 to 2000 | 32 to 3632 |
| 7 | Pt10%Rh/Pt40%Rh | "T023" 200 to 1800 | 392 to 3272 |
| 8 | Exergen K80 I.R. Pyrometer | "E-80" -45 to 650 | -49 to 1202 |
| Linear inputs | | | |
| M | -9.99 to +80mV | Scaleable | -1999 to 9999 |
| Y | 0 to 20mA (note 2) | Scaleable | -1999 to 9999 |
| A | 4 to 20mA (note 2) | Scaleable | -1999 to 9999 |
| V | 0 to 10Vdc (note 3) | Scaleable | -1999 to 9999 |
| Special input | | | |
| X | Special input | | |

| Units | |
|-------|--------------|
| C | °C |
| F | °F |
| K | Kelvin |
| X | Linear input |

| Input Adaptor | |
|---------------|-------------------------------------|
| XX | None |
| V1 | 0-10Vdc |
| A1 | 0-20mA sense resistor (2.49Ω, 0.1%) |

Note 1: Enter the minimum and maximum display range with the number of decimal places required (up to two). Thermocouple and RTD inputs will always display over the full range shown but the values entered here will be used as low and high alarm setpoint limits. For linear inputs, enter the display readings (with up to two decimal places) corresponding to the minimum and maximum input signal values.

Note 2: A 1% 2.49Ω current sense resistor is supplied as standard. If greater accuracy is required a 0.1% resistor can be specified in the input adaptor field.

Note 3: An input adaptor is required - see input adaptor field.

TECHNICAL SPECIFICATION

| | |
|----------------------------|--|
| Display | 4 digit, red or green, 15.9mm high characters |
| Calibration accuracy | ±0.25% of reading, or ± 1°C, or ± 1LSD whichever is the greater |
| Cold junction compensation | >15 to 1 rejection of ambient temperature change |
| Panel sealing | IP54 |
| Operating ambients | 0 to 55°C. Ensure that the enclosure is adequately ventilated. 5 to 95%RH, non condensing |
| Storage temperature | -30°C to +75°C. |
| Atmosphere | Not suitable for use above 2000m or in explosive or corrosive atmospheres |
| Power supply | 100 to 240Vac -15%, +10%, 48 to 62Hz, maximum consumption 5Watts |
| Relay rating (isolated) | Maximum: 264Vac, 2A resistive. Minimum operating voltage and current: 12Vdc, 100mA |
| Wire sizes | Use a minimum of 0.5mm ² or 16awg wire for plant connections. |
| Over current protection | Use independent 2A fuses for the indicator supply and relay outputs. Suitable fuses are EN60127 (type T) |
| Acknowledge/keylock input | Open circuit voltage: 22 volts. Nominal short circuit current: 20mA. Non-isolated from PV input. |
| Electrical safety | Meets EN 61010 (Voltage transients on the power supply must not exceed 2.5kV). Pollution degree 2. |
| Isolation: | All isolated inputs and outputs have reinforced insulation to protect against electric shock. (See live sensor note) |

SAFETY AND EMC INFORMATION

Safety

This indicator complies with the European Low Voltage Directive 73/23/EEC, amended by 93/68/EEC, by the application of the safety standard EN 61010.

Electromagnetic compatibility

This indicator conforms with the essential protection requirements of the EMC Directive 89/336/EEC, amended by 93/68/EEC, by the application of a Technical Construction File. This indicator satisfies the general requirements of the industrial environment defined in EN 50081-2 and EN 50082-2.

GENERAL

The information contained in these instructions is subject to change without notice. While every effort has been made to ensure the accuracy of the information, Action Instruments, Inc. shall not be held liable for errors contained herein.

Unpacking and storage

The packaging should contain the indicator, two panel retaining clips, a 2.49Ω current sense resistor, a peel off label set and this instruction leaflet.

If the packaging or the indicator are damaged, do not install it but contact the company where you purchased the product.

SERVICE AND REPAIR

This indicator has no user serviceable parts. Contact your nearest agent for repair.

Caution: Charged capacitors

Before removing the indicator from its sleeve, switch off the supply and wait two minutes to allow capacitors to discharge. Failure to observe this precaution may damage the indicator or cause some discomfort to the user.

Electrostatic discharge precautions

When the indicator is removed from its sleeve, it is vulnerable to damage by electrostatic discharge from someone handling the indicator. To avoid this, before handling the unplugged indicator discharge yourself to ground.

Cleaning

Do not use water or water based products to clean labels or they will become illegible. Isopropyl alcohol may be used to clean labels. A mild soap solution may be used to clean other exterior surfaces of the product.

Safety Symbols

The following safety symbols are used on the controller:



Caution, (refer to the accompanying



Functional earth (ground) terminal

Personnel

Installation must be carried out by qualified personnel.

Enclosure of live parts

The indicator must be installed in an enclosure to prevent hands or metal tools touching parts that may be electrically live.

Caution: Live sensors

The alarm acknowledge/keylock inputs are electrically connected to the sensor input (e.g. thermocouple). In some installations the temperature sensor may become live. The indicator is designed to operate under these conditions, but you must ensure that this will not damage other equipment connected to the acknowledge/ keylock inputs and that service personnel do not touch this connection while it is live. With a live sensor, all cables, connectors and switches for connecting the sensor and non-isolated inputs and outputs must be mains rated.

Wiring

Wire the indicator in accordance with the wiring data given in these instructions. Take particular care not to connect AC supplies to the low voltage sensor input or logic outputs. Only use copper conductors for connections, (except thermocouple). Ensure that the installation complies with local wiring regulations.

Power Isolation

The installation must include a power isolating switch or circuit breaker that disconnects all current carrying conductors. The device should be mounted in close proximity to the indicator, within easy reach of the operator and marked as the disconnecting device for the indicator.

Voltage rating

The maximum continuous voltage applied between any connection and ground must not exceed 264Vac.

For the above reason the indicator should not be wired to a three phase supply with an unearthed star connection. Under fault conditions such a supply could rise above 264Vac with respect to ground and the product would not be safe.

Conductive pollution

Electrically conductive pollution must be excluded from the cabinet in which the indicator is mounted. For example, carbon dust is a form of electrically conductive pollution. Where condensation is likely, for example at low temperatures, include a thermostatically controlled heater in the cabinet.

Installation requirements for EMC

- It may be necessary to fit a filter across the relay output to suppress conducted emissions. The filter requirements will depend on the type of load. For typical applications we recommend Schaffner FN321 or FN612.

Routing of wires

To minimize the pick-up of electrical noise, the sensor input wiring should be routed away from high-current power cables. Where it is impractical to do this, use shielded cables with the shield grounded at both ends.